

Pressure and Quantity Thresholds for Ignition of Oil Contamination by Rapid Pressurization in Oxygen Systems

Susana Tapia, Sarah Smith, Steve Peralta, and Joel Stoltzfus
NASA White Sands Test Facility



Problem Statement

- **Problem:**
 - Oil contamination produces an increased ignition hazard in oxygen systems
- **Solution:**
 - Determine oil quantity and oxygen pressure thresholds



Experimental

- Perform rapid pressurization tests
 - Common ignition mechanism in oxygen systems
- Contamination level threshold
 - Determine quantity of oil (sebum) deposited by handling hardware with bare hands
 - Determine quantity of oil (sebum) required to obtain a burning reaction during rapid pressurization to 4000 psi
- Oxygen pressure ignition threshold
 - Use highly volatile hydrocarbon oil (WD-40) on open-cell polyethylene foam
 - Determine minimum ignition threshold as a function of pressure



Contamination Level Threshold

- The oil on the surface of the skin is a complex mixture of sebum oil, lipids, sweat, and environmental materials
- Synthetic sebum selected for tests

TABLE 1—*Composition of synthetic sebum (Lot #9183).^a*

Composition	
10 %	Palmitic acid
5 %	Stearic acid
15 %	Coconut oil
10 %	Paraffin wax
15 %	Synthetic spermaceti
20 %	Olive oil
5 %	Squalene
5 %	Cholesterol
10 %	Oleic acid
5 %	Linoleic acid

^aSynthetic sebum is a product of Scientific Services S/D, Inc., 42 Main Street, Sparrow Bush, NY, 12780. (Treated to remove peroxides and flushed with nitrogen in order to prevent polymerization and oxidation; contains trace water; is stable at ambient conditions in the absence of air; nitrogen padded.)




Contamination Level Threshold

- Properties of sebum oil
 - Heat of Combustion
 - ~39.7 KJ/g
 - 90% of hydrocarbon-based oil
 - Auto Ignition Temperature
 - 139 ± 7 °C
 - Silicone grease AIT = 216 °C




Contamination Level Threshold

- Evaluated contamination level due to handling without gloves
 - Five technicians
 - Four separate occasions
 - “Flip & Grip” test coupons
 - $\text{NVR} = 14 \pm 5 \text{ mg/m}^2$





Contamination Level Threshold

- Rapid pressurization according to ASTM G74
- Oil coated cylindrical rods
- Varied surface concentration (9000 mg/m²)
- Tested at 4000 psi (27.6 MPa)





Detection Technique



July 2009

Oil Con



Contamination Level Threshold

- Threshold surface concentration was 150 mg/m²
- Next highest concentration tested was 340 mg/m²
- Hand oil contamination maximum 20 mg/m²

Contamination level (mg/m ²)	Number of reactions/ number of tests
9,000	1/3
3,200	1/12
540	1/27
340	1/16
150	0/40



Oxygen Pressure Level Threshold

- Rapid pressurization according to ASTM G74
 - Each sample subjected to 5 consecutive pneumatic impact events for each test data point
- Minicell L-200 polyethylene foam samples
- Contaminated with WD-40
- Tested at various oxygen pressures



Oxygen Pressure Level Threshold

- A reaction occurred at 300 psia
- No reactions occurred at 275 psia in 80 tests

Impact Pressure		Number of Reactions	Number of Samples Tested
(Mpa)	(psia)		
2.4	350	1	20
2.1	300	0	20
2.1	300	1	4
1.9	275	0	20
1.9	275	0	20
1.9	275	0	20
1.9	275	0	20

From WSTF Number 06-40281



Summary

- Contamination level threshold
 - Sebum (fingerprint) oil
 - 4000 psi rapid pressurization
 - Between 150 and 340 mg/ft²
 - Fingerprints could contribute to other oil contamination
- Oxygen pressure level threshold
 - WD-40 oil
 - Standard rapid pressurization test system
 - Between 275 and 300 psia
 - Below 275 psia (minus your desired margin) no ignition due to rapid pressurization